

Support the chip listing :

51 serials :

AT89S51 ` AT89S52 ` AT89S53 ` AT89S8252

AVR serials ♂

ATTiny12(L) ` ATTiny13(V) ` ATTiny15(L) ` ATTiny24(V) ` ATTiny25(V) `
ATTiny26(L) ` ATTiny2313(V) ` ATTiny44(V) ` ATTiny45(V) `
ATTiny84(V) ` ATTiny85(V) ` AT90S2313(L) ` AT90S2323(L) `
AT90S2343(L) ` AT90S1200(L) ` AT90S8515(L) ` AT90S8535(L) `
ATMEGA48(V) ` ATMEGA8(L) ` ATMEGA88(V) ` ATMEGA8515(L) `
ATMEGA8535(L) ` ATMEGA16(L) ` ATMEGA162(V) ` ATMEGA163(L) `
ATMEGA164(V) ` ATMEGA165(V) ` ATMEGA168(V) ` ATMEGA169(V) `
ATMEGA169P(V) ` ATMEGA32(L) ` ATMEGA324(V) ` ATMEGA325(V) `
ATMEGA3250(V) ` ATMEGA329(V) ` ATMEGA3290(V) ` ATMEGA64(L) `
ATMEGA640(V) ` ATMEGA644(V) ` ATMEGA645(V) ` ATMEGA6450(V) `
ATMEGA649(V) ` ATMEGA6490(V) ` ATMEGA128(L) ` ATMEGA1280(V) `
ATMEGA1281(V) ` ATMEGA2560(V) ` ATMEGA2561(V) ` AT90CAN32 `
AT90CAN64 ` AT90CAN128 ` AT90PWM2(B) ` AT90PWM3(B)

NOTE : ⌵ATMEGA16(L)⌵ is talk about two chips:ATMEGA16 and ATMEGA16L

Driver : <http://www.fischl.de/usbasp/>